

Protect your facility and workers from these common worksite hazards.



- 1 Tool Drop Zone** - Barricade zones below higher work levels to prevent personnel from walking into the line of fire of a dropped object.
- 2 Confined Space** - Always section off confined spaces with a durable and easy-to-see barrier to prevent accidents.
- 3 Machine Guarding** - Avoid workplace injuries and costly fines by safeguarding your machinery when not in use.
- 4 Electrical Equipment** - Effectively identify high voltage electrical equipment and arc flash boundaries to keep people at a safe distance.
- 5 Forklift Traffic** - Keep workers safe from forklift traffic in work zones and walkways with a highly visible safety barrier.
- 6 Spills/Hazardous Areas** - Prevent slips, trips, and falls by sectioning off an entire area when spills occur to warn others.
- 7 Dock Doors** - Quickly deploy an immediate warning when dock doors are open to help prevent falls.
- 8 Maintenance/Cleaning** - Safely close spaces like elevators and restrooms when cleaning or maintenance needs to be done.



Maintenance/Cleaning



Forklift Traffic



High Voltage / Arc Flash



Machine Guarding

Highly Visible Barriers Promote Safer Work Environments



Clearly communicate when a machine is closed for repairs, to keep people safe.



Barriers effectively alert people of potential hazards and spills.



Lockout/tagout barriers add an extra element of safety to reduce risk.



Close areas while they are being cleaned.



For all your safety barrier needs, *contact us today!*
(855) 809-3800 | sales@bannerstakes.com